



**Safety Recalls for the United Kingdom available on the Web**

---

## **Zanussi Electrolux Dishwashers**

**Dishwasher MODELS DE6850 & DE6855**

**OWNERS OF THE ABOVE APPLIANCE MUST ACT IMMEDIATELY ON THIS SAFETY NOTICE.**

A Quality Control programme has identified a small number of dishwashers which may have a faulty electrical connection that could overheat. This could result in the dishwasher catching fire. If you are the owner of one of these Zanussi Electrolux Dishwashers, please stop using the appliance immediately and isolate it from the electrical supply. The model and serial number of the dishwasher is clearly printed on the rating plate on the inside of the dishwasher door and should be checked against the affected range in the table below.

**Model no  
PNC No  
Serial no between**

**DE6850  
911915047  
34370001-34370330**

**DE6850  
911915047  
34440001-34440450**

**DE6855  
911915048  
34370001-34370100**

**Should your dishwasher model and serial number details match those in the table,  
Please contact them by:**

**Telephone: Freephone 0800 33 43 53 between 8.00am and 6.00pm Monday-Friday,  
9.00am and 5.00pm Saturday-Sunday**

**Or E-mail: [safetynotice@electrolux.co.uk](mailto:safetynotice@electrolux.co.uk)**

**This safety notice does not affect any other Zanussi Electrolux Dishwasher or any other Zanussi Electrolux appliance. They apologise for any inconvenience this may cause and thank you for your co-operation.**